



# SOFA

## BALANCE PLUS




(for C0130001. only)


Armchair  
**C0130001.3A**  
Extra Cover  
**Y1030001.**





Armchair  
**C0130002.3A**  
Extra Cover  
**Y1030002.**



Three Seater Sofa  
**C0130003.3A**  
Extra Cover  
**Y1030003.**




Three Seater Sofa  
**C0130004.3A**  
Extra Cover  
**Y1030004.**




## BALANCE PLUS

Four Seater Sofa  
**C0130005.3A**  
Extra Cover  
**Y1030005.**




## BALANCE PLUS


LAF Chaise  
**C0130007.3A**  
Extra Cover  
**Y1030007.**




RAF Chaise  
**C0130008.3A**  
Extra Cover  
**Y1030008.**



LAF Sofa  
**C0130009.3A**  
Extra Cover  
**Y1030009.**




RAF Sofa  
**C0130010.3A**  
Extra Cover  
**Y1030010.**



Extra Cover  
**Y1030006.**




LAF Chaise  
**C0130013.3A**  
Extra Cover  
**Y1030013.**




RAF Chaise  
**C0130014.3A**  
Extra Cover  
**Y1030014.**



LAF Chaise  
**C0130011.3A**  
Extra Cover  
**Y1030011.**



RAF Chaise  
**C0130012.3A**  
Extra Cover  
**Y1030012.**



Cushion  
**C8130002.**  
Extra Cover  
**Y8130002.**



Cushion  
**C8130007.**  
Extra Cover  
**Y8130007.**



Cushion  
**C8130003.**  
Extra Cover  
**Y8130003.**



Cushion  
**C8130005.**  
Extra Cover  
**Y8130005.**

